

# Wood Duck / Screech Owl BOX BUILD INSTRUCTIONS



## Tools Required

A 16-gauge air nail gun works great for assembly. A standard hammer and nails will work, but wood screws would be preferred. Weather resistant glue is recommended. An electric hand drill is also required.



Wood duck box pictures shown...

Screech owl boxes follow the same build procedure

## Step 1

Attach fixed side panel to back, keep flush at top. Side panels are wider than doors, do not mix up.

## Step 2

Attach floor, keep floor recessed up about 3/8 inch. (Not absolutely necessary)

Note location of drainage slot in photo. (This is very important for proper fit)

## Step 3

Attach front, keep flush at top and along side panel.



### Step 4

Attach roof, keep flush with back and side panel.



### Step 5

Attach door with 2 supplied wood screws, allow a 1/8 inch gap at top and do not over tighten screws as this will restrict door movement.



### Step 6

Drill 3/16 inch diameter hole through front, into the door on a 10 to 15 degree angle as shown in photo. Drill deep enough to allow the pin head to mount flush. Photo shows pin partially installed to illustrate angle of hole. (The angled hole will keep the pin from falling out)



### Step 7

Attach perch approximately 5 inches below bottom of entrance hole.

(Note: Attach perch 4 inches below for screech owl box)

